# Fiber-GRIN Alignment tool KLZ 16/0422

PROJECT NUMBER: 12422 (HYAZINT)

**CLEANROOM START: 29.07.2016** 

**CLEANROOM END: 31.08.2016** 

## Short description of the fabricated chips:

#### **SUBSTRATES:**

• 1 x Si-SiOx(400 nm)-Nitride(108 nm), DSP, 100 mm, Batch 068 Ox3, 380 μm

#### STRUCTURES:

• KOH etched grooves for alignment

#### MASK SET:

• "0 KOH"

	Process	Comments
1.	HMDS-priming:	
	• HDMS hotplate (Program 1)	
2.	Spin Coating of positive resist:	
	• Nominal thickness: 1.8 μm	Profilometer: 2 um PR thickness
	• Statically dispense 2.0 mL of AZ1518 (Position 4 on	measured
	25 mL syringe)	
	• Recipe 4: 4000 rpm, 30 sec	
3.	Softbake: □	
	• 100°C, 50 s	
4.	Exposure: "0 KOH"	
	Flat alignment, foil mask, soft contact	
	• Exposure time: <b>5 s</b> = 2.8 s x 1.8 @ 9mW	
5.	<u>Develop</u> □	
	Program P	
6.	Structure oxide: RIE (STS)	He leakage rate > 50 mT/min. Etched
	Nitride thickness: 108 nm	anyway. No problems visible.
	• Oxide thickness: 400 nm	
7.	Resist stripping	

Process Comments

### 8. KOH Etching

• Desired depth: 180 um Measured depth: 183 um

• Concentration: 30 %\

• T = 80 C

• Depth tolerance: > 180 um